

# **HYPERPRO** *Racing Shock* TYPE 460/461

INSTRUCTION SHEET BMW 11500 RT REAR 2001>  
BM11-0AE-SXHH / BM11-1AE-SXHH

- Place the bike on the center stand and remove the current shock absorber.
- Place the Hyperpro shock in the bike, type 461 with reservoir as shown in the picture. If your shock is equipped with the optional hydraulic preload adjuster place the banjo bolt of the HPA to the right side of the bike.
- Use the two added clamps and rubber blocks to mount the reservoir on the sub frame.



- Route the hose of the HPA as shown in the picture
- Use the added hardware to mount the adjuster knob on the added bracket.
- Use the original place and bolt for mounting the adjuster knob bracket
- See next page

# **HYPERPRO** *Racing Shock* TYPE 460/461



- Make sure all the hoses are not obstructed
- Make sure the fairing will fit over the reservoir and adjuster knob
- Place all the bolts back and tighten them with the proper torque

## **ADDED HARDWARE :**

Bolt M6x25	2 pcs
M6 Nyloc nut	2 pcs.
Washer M6	4 pcs
Bracket 3d-BR-00-03	1 pc